

P1 Filter Change Instructions

Diagram 2: Shut off valve



Diagram 1: Pre-Filters

Set up: P1 only, or P1, P2, P3



The blue cap is in on position (water is flowing)



The blue cap is in off position (water is not flowing)

1. Locate pre-filters under the sink. (diagram 1)
2. Shut off the water flow at the blue shut off valve attached to the "IN" water line of the pre filters. (diagram 2)
3. Run the water on both sides of the faucet to make sure no more water is coming out.
4. Twist off P1 filter by turning it clockwise until it stops and then pull vertically down to remove.
5. "Align" the new P1 filter under the empty slot properly. Once aligned, push it vertically up and then turn counter-clockwise all the way until it stops.
6. Turn on the water flow at the blue shut off valve. (diagram 2)
7. Flush the system for 3-5 mins.
8. Check and make sure there are no leaks.

Product Support Page:
www.springaqua.com/product-support

text: +1-206-880-7766
email: bill@springaqua.com
Or Schedule a time on calendar
visit www.springaqua.com/contact-us